


The Analogue Film Academy © 2016

Shutter Synchronisation

When the claw is going down the shutter needs to be closed covering the film gate so that the film is not exposed whilst the film moves..

When the claw is going up, the film is stationary and the shutter has to be open to allow the film to be exposed correctly.

To check correct synchronisation remove the front name panel



The correct position of the claw
[Pressure plate with holder is taken
off with 2.5mm Allen Key]

The correct position of the
shutter